



*Accurately and evenly adjust the hopper for precision pasting.*

- Easy to use controls
- Incremental adjustments as small as .001"



- Sensors on each corner display exact hopper position on panel screen
- Tight control over pasting quality



- Servo Motors for precision control
- Four corner support for perfectly level adjustments
- Interface with Mate Gage for closed loop control.

